The steps below can guide you in using the glass ceramic or induction hot plates. Please, note that the induction hot plates work ONLY with pots & pans manufactured for induction hot plates. This means aluminium and stainless steel dishes cannot work if they have no integrated iron plates/pieces in the

bottom. Usually the dishes have the following sign which shows that they can be used with induction hot plates. IMPORTANT: in case of induction hot plates you need to palce the pot/pan first on the glass surface otherwise it will not work and it will show error.



Step 1: locate the ON/OFF button (O/I)



Step 2: hold your finger for a couple of seconds on the O/I button to turn the hot plates ON



Step 3: now you choose the hot plate you want to use (fx. the smaller in the picture)



Step 4: hold your finger on the button to adjust the temperature to the desired level (0~9). It is set now on level 4 in the picture.











Step 5: or it is set on level 9 (as per in the picture)

Step 6: hold your finger on the button to lower the temperature level. It is set now on level 4 in the picture.

Step 7: the other (bigger) hot plate works the same way

Step 8: you can always turn the hot plates OFF with the O/I button (holding your finger on it for a couple of seconds)

Step 9: the hot plates are turned OFF now. The letter "H" on the display worns you that the hot plates are still very HOT – avoid touching them!